




HARDENED WOOD FLOORING USAGE CLASS CHART

URBAN SURFACES

	Class	Symbol	Level of Use	Description	Examples of Areas of Use
Domestic				**Areas considered for residential use**	
	21		**Moderate**	Areas with low or intermittent use	Bedroom, dining room
	22		**General**	Areas with medium use	Children's room, living room, entrance hall
	23		**Heavy**	Areas with intense use	Kitchen, living room, corridor, office, entrance hall
Commercial				**Areas considered for public & commercial use**	
	31		**Moderate**	Areas with low or intermittent use	Bedroom, hotel, conference room, small office
	32		**General**	Areas with medium traffic	Classroom, small office, hotel, bontqiue, conference room, doctor's practice
	33		**Heavy**	Areas with heavy traffic	Corridor, department store, school, multi-purpose hall, open plan office, reception
	34		**Very Heavy**	Areas with instense use	Airport, multi-purpose hall, counter hall, department store
Industrial				**Areas considered for light industrial use**	
	41		**Moderate**	Areas where work is mainly sedentary with occasional use of light vehicles	Electronic assembly, precision engineering
	42		**General**	Areas where work is mainly standing and/or with vehicular traffic	Storage room, electronic assembly
	43		**Heavy**	Other light industrial areas	Storage room, production hall